



ANSER U2 Trouble Shooting User Manual

Version : 1.0

Update: Sep. 10th, 2010



InkJet, Inc. ®

11111 InkJet Way

Willis, TX 77378-5908

Toll-free: (800) 280-3245

Fax: (936) 856-4524

<http://www.inkjetinc.com/>


Index

I. Definition of LED status on U2.....	1
II. Non-printing Flow Chart	2
III. Missing Lines When Printing Flow Chart	3

I . Definition of LED status on U2

LED	Status	Definition
RUN	Printer is power on	Light on
	Printer is power off	Light off
PRINT	Printer is printing	Light on
	Printer is not in printing process	Light off
	Printer is waiting for Encoder signal	Flashing
INK LOW	The remaining of the ink volume is low	Light on
	The ink is adequate	Light off
ALARM	These are some issues in the printing system	Light on
	System is running smoothly	Light off
REMOTE	The keypad is available to operate the printer	Light on
	The keypad is unavailable to operate the printer	Light off

II. Non-Printing Flow Chart



III. Flow chart for missing lines when printing

